



HOW TO USE THE SPRING TECH TOOL

MERITOR SLACK ADJUSTERS —DO NOT ATTEMPT TO ROTATE THE CAM BACKWARDS WITH AUTOSLACKS WITHOUT RELEASING THE PAWL.

Removal

- Rotate the S cam so that the brakes are in the full released position - insure that the cam is rotated to seat the rollers are in the lowest position.
- Slide the Spring Tech Tool between the shoe webs over the top roller and hook the top of the return spring below the coil.
- Push down on the handle and unhook the spring from the pin by pulling back or pushing forward on the handle depending on the direction of the spring opening.

Installation

- Install both the roller and the roller retainers in both shoes.
- Install the return spring pins if required.
- Install the top shoe - insure that the cam is rotated to seat the roller in the lowest position.
- Hang the anchor springs from the top shoe.
- Attach the lower shoe, with the anchor springs, and then rotate the lower shoe into position.
- Install the return spring on the lower shoe with the upper spring opening facing the roller.
- Slide the Spring Tech Tool between the shoe webs over the top roller and hook the top of the return spring below the coil.
- Push down on the handle and hook the spring over the pin by pulling back on the handle.

